

## PERMAPAK ACCESSORIES



### Anchor Latch Assembly

The **Anchor Latch Seal Assembly** is used when floating seals are not required. This assembly allows the tubing string to be in tension or compression. Upon set down the anchor latches into the packer and can be removed with eight to ten right-hand turns.



### Snap Latch Assembly

The **Snap Latch Seal Assembly** latches into the packer upon set down (like our Anchor Latch Seal Assembly). It can be removed with straight pull of 10,000 to 12,000 lbs. above tubing weight. The Snap Latch Seal Assembly is used where a mechanical indication is required to verify the seal assembly is properly positioned in the packer bore.



### Seal Unit

The standard **Seal Unit** is furnished with bonded nitrile rings and a 12-inch make-up length. These units may be ordered in various lengths and with severe service seal rings for high temperature and corrosive environmental conditions.



### Locator Seal Assembly

The **Locator Seal Assembly** is used in installations which require floating seals. Once landed, the seal locator prevents downward movement of the tubing while allowing the seal to move with tubing contraction.



### Half Mule Shoe Guide

The **Half Mule Shoe Guide** is standard with the Seal Assembly to allow for easy entry into the packer bore.

Permanent Packers