

PUMP-OUT PLUG

The **Pump-Out Plug** is available with a variety of threads allowing installation to the bottom of the tubing string to isolate the tubing from the annulus. To remove the plug, pressure is applied to the tubing and the Pump-Out Plug is removed to allow full opening. The pump-out pressure value is easily adjusted in the field by adding or removing shear screws. Also available with ball seat.

Special Features

- Ball seat available
- Adjustable shear value (high shear available)
- Special Pump-Out Plug designs available



Pump-Out Plug
w/ Shear Screws

Product Specifications

Tubing Size (inches)	Tool OD (inches)	Tool ID (inches)	Thread Connection Box Up	Part Number
1.050	1.660	-	1.050 EUE	59710E
1.315	1.900	1.20	1.315 EUE	59713E
1.660	2.062	1.38	1.660 NUE	59716N
	2.200	1.38	1.660 EUE	59716E
1.900	2.500	1.50	1.900 EUE	59719E
	2.200	1.50	1.900 NUE	59719N
2-3/8	3.060	2.00	2-3/8 EUE	59720E
2-7/8	3.670	2.50	2-7/8 EUE	59727E
3-1/2	4.500	3.46	3-1/2 EUE	59735E
		2.88	3-1/2 EUE	59736E
4-1/2	5.560	4.00	4-1/2 EUE	59745E
			4-1/2 LTC	59745LTC
5-1/2	6.000	5.13	5-1/2 LTC	59755LTC
6-5/8	7.390	6.23	6-5/8 LTC	59766LTC
7	7.650	6.60	7" LTC	59770LTC
8-5/8	9.620	8.18	8-5/8 LTC	59786LTC
9-5/8	10.620	9.17	9-5/8 LTC	59796LTC



Pump-Out Plug
w/ Shear Screws
and Ball Seat

OPTIONS: Available with high shear, also with ball and ball seat.

NOTE: All pricing includes standard Nitrile trim. Other sizes and connections available upon request.